

EX- tila



OLCT 50/ O2
 EEXd IIC T6
 II 2 GD
 Ineris 01 ATEX 0004
 EN 50270

Paikallinen näyttö ja hälytysyksikkö SX 500DRV/ EA IP 65



← 24 VDC
 → 4-20mA

← 24 VDC
 → 4-20mA
 ← 0 VDC


24 VDC / rele A1

Sulkeutuva kontakti
 max 230 VAC 100 mA

DDC system
 tai
 AVA-UNIT 12
 Keskus

Poweri
 24VDC

EX vilkku
 TNFCDM
 24 Vdc



→ 0 VDC

OLCT 50 /SX 500DRV/EA	17.10.2002
<h3>Sensorex oy</h3> <p>p.02-4340750 f. 02-4350643</p>	